



大埔文娛中心 演奏廳 額外供電平面圖
Tai Po Civic Centre Auditorium Power Outlet Plan

(1) 63A 3-phase
CEE form socket

- 21. LXC
- 19. REAR CURTAIN
- 17. SPARE AMP 1
- 16. SPARE AMP 4
- 15. SPARE AMP 3
- 14. LXC 2
- 13. LXC 1
- 14. LEGS 3
- 13. HURDLE 3
- 12. LXC 4
- 11. SPARE AMP 2
- 10. LXC 3
- 9. LEGS 2
- 8. HURDLE 2
- 7. LXC 2
- 6. SPARE AMP 1
- 5. LEGS 1
- 4. HURDLE 1
- 3. LXC 1
- 2. HOUSE CURTAIN
- 1. TEASER

